

How to Apply RESTORE the Right Way?

Before You Begin

1) Clean 2) Degrease



3) Application



Step 1:

Gently shake the Restore



Step 3:

Work in small areas, ensuring even application and no streak marks.



Step 5:

Apply a single layer of Restore coating and let it dry for at least 5 days.



Step 2:

Open the lid and apply a generous amount to a dry, new applicator



Step 4:

Allow the product to dry for 30 seconds. Use two 380 gsm microfiber cloths: one to wipe off the bulk of the coating & the other to wipe off any remaining residue. Inspect the surface to ensure there are no haze marks.

How to Maximize Results?

- Avoid direct sunlight.
- Work small sections at a time.
- Inspect the surface to ensure there are no haze marks.
- ✓ Use minimum 380 gsm cloths to wipe off coating for the best results.