

How to Apply OVERLAY the Right Way?



Before You Begin

Install the Paint Protection Film (PPF) as per the manufacturer's instructions.

Overlay Application Process:



Step 1:
Wipe down the PPF with diluted IPA.



Step 2:
Gently shake the Overlay bottle. Open the lid and apply a generous amount to a dry, new applicator pad.



Step 3:
Apply the coating in a cross-hatch pattern on a small area. Ensure the coating is applied evenly to avoid any high spots.



Step 4:
Wipe off the coating immediately (max 30 seconds) after application on the panel. Use two microfiber cloths to wipe off the coating: one to remove most of the coating and the second to wipe off any leftover residue.



Step 5:
The vehicle can be driven after 24 hours. However, avoid manual washing for upto 7 days & reduce contact with water if possible.

How to Maximize Results?

- ✔ Work small sections at a time
- ✔ Avoid direct sunlight.
- ✔ Inspect the surface to ensure no spots are missed.
- ✔ Use minimum 380 gsm cloths to wipe off coating for the best results.

Please Note: Ensure the PPF or wrap is solvent-resistant. Perform a small patch test before full application. Overlay is not suitable for matte surfaces.