

How to Apply INFINITY the Right Way?

Before You Begin

- 1) Wash
- 2) Machine Polish
- 3) De-Contaminate & Degrease
- 4) Mask all trim, glass, plastic and rubber components on the vehicle



Infinity Application Process:



Step 1: Shake Both Bottles

Gently shake Part A – Resin and Part B – Hardener before opening.



Step 2: Mix Part A & Part B

Pour equal quantities (50mL each) of Part A and Part B in the provided empty bottle. Do not mix more than 100mL liquid at a time. Mix gently until Part A and B are completely mixed.

No waiting period is required. Once Part A and Part B are mixed, Infinity is ready for immediate application.

Important: The mixed formula must be used within 45 minutes



Step 3: Saturate the Applicator Cloth

One 40 × 40 cm microfiber cloth is included. Cut it into four equal pieces and use one piece at a time. Apply enough mixed coating to completely saturate the cloth before application.



Step 4: Apply Coating

Apply Infinity to the panel using a straight line pattern or circular motion and passing over once only.

DO NOT WIPE THE COATING OFF. Ensure a thick layer of coating is spread evenly and consistently across the panel.



Step 5: Inspect the Panel

Carefully inspect the panel under suitable lighting to ensure:

- The coating is evenly distributed
- No high spots are visible
- No areas have been missed
- The surface is free from visible unevenness
- If you see any uneven lines, they should disappear within 30 minutes unless applied incorrectly.

How to Maximize Results?

- ✓ Ensure the applicator cloth is completely saturated before application.
- ✓ Use an **air blower** to assist with quicker drying and even distribution after coating is applied. Use air blower within 2 minutes of applying coating per panel.
- ✓ Avoid direct sunlight during application
- ✓ Inspect each section carefully before moving to the next.
- ✓ Do not apply more than 1 layer of Infinity.

Troubleshoot:

- Coating can be removed whilst still wet using a PU thinner (available at most hardware or paint stores)
- To remove coating after full cure, it needs to be wet sanded.
- Coating can be polished after 3 days to correct any imperfections.